

Instructions for use

Drainage channel with Triflex Framebox



Drainage channel with Triflex Framebox

Primer:

Clean Triflex Framebox with Triflex Cleaner and prime with Triflex Metal Primer. Then lay out and align the Triflex Framebox.

Important:

Make the inner and outer corners by cutting into the flanges and bending.



Lay out the fleece:

Cut the appropriate fleece cut-outs from the Triflex Special Fleece and lay them out in the Triflex Framebox.

Place the drain socket:

Placement of the drain nozzle DN 40 in the Triflex Framebox, for lateral drainage via pipe connection. Alternatively, drainage can be linear in a downwards direction.

Tip:

Consider connection to the main drainage system.



Detail waterproofing:

Waterproof the surface, floor recess profiles, thresholds and the masonry reveal with Triflex ProDetail.

Creating the gradient:

Remove the aligned Triflex Framebox from the substrate and create a gradient in the direction of the drain using Triflex Cryl Level 215+ or Triflex CeFix Screed 631.



Laying out the ACO Frameline:

Lay out the ACO Frameline and shorten it to the appropriate length if necessary.

Then screw the ACO Fit in height adjusters to the ACO Frameline and adjust to the appropriate height with a screwdriver.

Fill the surface:

Insert the Triflex Framebox into the freshly created gradient. Fill the surface with Triflex Cryl Level 215+, Triflex CeFix Screed 631 or the Triflex BIS System and join it up with the Triflex Framebox.

Important:

Minimum gradient 2 %, top edge in the direction of the surface drain socket or rainwater gutter.



Insert the grating:

Insert ACO mesh grating or grating with longitudinal bars.

International

Triflex GmbH & Co. KG
Karlstrasse 59
32423 Minden | Germany
Fon +49 571 38780-708
international@triflex.com
www.triflex.com

